

Power
Turns components On/Off

TV
Controls TV functions

STB
Used for Set Top Box functions

Rewind/Play/Pause/ Fast Forward/Stop
For use with PVR/VCR/DVD/VOD Functions

Menu
Displays main menu

Info
Displays information about current program

OK
Press when you want to select a program or highlighted object

Arrows
Allows you to scroll through the guide and menu

Guide
Displays programming guide

Exit
Exits the guide and menu

Page Back/Forward
Scrolls Side to Side from the current page in the guide

Page Up/Down
Scrolls Up and Down from the current page in the guide

Red/Green/Yellow/ Blue Buttons
Only used for menu functions

Volume +/-
Increases/Decreases volume

Channel +/-
Changes channels on the STB

Last
Returns your programming back to the previous channel

Number Keys
Used for typing in channels numbers and alphabet letters

Delete
Deletes single character in text entry boxes

Closed Captioning
Enable/Disables Closed Captioning

Input
Switches between audio video inputs on your TV

Turning ON and OFF Television
To turn on TV press TV then **POWER**
Press STB to control our set top box
To turn off TV press TV then **POWER**

